



SM-R770, SM-R760, SM-R765

Gear S3 호환모델

삼성제품	모델명	지원여부	비고
Galaxy On7 [®]	SM-G610S/K/L	●	
Galaxy J5	SM-J500S/K/NO	●	
Galaxy J3 [®]	SM-J320S/K/L/NO	●	
Galaxy J5 [®]	SM-J510S/K/L	●	
Galaxy J7 [®]	SM-J710K	●	
GALAXY A ⁵	SM-A500S/K/L	●	
GALAXY A ⁷	SM-A700S/K/L	●	
Galaxy A3 [®]	SM-A310S/K/L/NO	●	
Galaxy A5 [®]	SM-A510S/K/L	●	
Galaxy A7 [®]	SM-A710S/K/L	●	
Galaxy A8 [®]	SM-A810S	●	
Galaxy A8	SM-A800S	●	
GALAXY ALPHA	SM-G850S/K/L	●	
GALAXY GRAND 2	SM-G710S/K/L	●	
GALAXY MEGA	SHV-E310S/K/L	●	
GALAXY Note II	SHV-E250S/K/L	●	
GALAXY Note 3	SM-N900S/K/L	●	
GALAXY Note 3 [™]	SM-N750S/K/L	●	
GALAXY Note 4	SM-N910S/K/L	●	
GALAXY Note 4 ^{S-LTE}	SM-N916S/K/L	●	
GALAXY Note Edge	SM-N915S/K/L	●	
Galaxy Note5	SM-N920S/K/L	●	
GALAXY ROUND	SM-G910S	●	
GALAXY S III	SHV-E210S/K/L	●	
GALAXY S III (3G)	SHW-M440S	●	
GALAXY S ⁴	SHV-E300S/K/L	▲	· 기어 S3의 S헬스와 연동 미지원
GALAXY S ⁴ ACTIVE	SHV-E470S	●	
GALAXY S ⁴ LTE-A	SHV-E330S/K/L	●	
GALAXY S ⁴ mini	SHV-E370K	●	
GALAXY S ⁵	SM-G900S/K/L	●	
GALAXY S ⁵ MINI-A	SM-G906S/K/L	●	
Galaxy S6	SM-G920S/K/L	●	
Galaxy S6 edge	SM-G925S/K/L	●	
Galaxy S6 edge+	SM-G928S/K/L	●	
Galaxy S7	SM-G930S/K/L	●	
Galaxy S7 edge	SM-G935S/K/L	●	
GALAXY ZOOM 2	SM-C115L	●	
GALAXY W	SM-T255S	●	
Galaxy Wide	SM-G600S	●	

[타사 안드로이드 제품]

- G Pro2(LG-F350S), 옵티머스G3(LG-F400), G4(LG-F500), G5(LG-F700), 넥서스5(LG-D821), V10(LG-F600), Moto X(XT1902), 베가아이언2(IM-A910S), 엑스페리아 Z3(D6653), Mi4

[iOS 제품]

- iOS 9.0 이상 & iPhone5 이상 모델 (단, iOS 10.X 버전의 iPhone 6S, 6S+에서는 기어와의 연결이 불안정할 수 있습니다.)

※ 기어 S3는 안드로이드 4.3(타사 스마트 폰은 4.4), RAM 1.5 GB 이상을 제공하는 스마트폰 및 iOS 9.0 이상 & iPhone5 이상의 스마트폰과 호환됩니다. 다만, H/W 사양, S/W OS버전 등에 따라 호환이 되지 않거나 일부 기능의 사용이 제한될 수 있으니 상기 '기어 S3 호환 모델'에서 확인하시기 바랍니다.

※ iOS 10.X 버전의 iPhone 6S, iPhone 6S+와 기어와의 연결이 지속적으로 불안정한 경우, 기어 S3의 핸드프리 연결을 포함한 다른 Bluetooth 기기의 연결을 해제 하신 후, Bluetooth를 껐다가 다시 켜시기 바랍니다.