


Product fiche

REGULATION (EU) No 1059/2010

 * * * Asterisk(s) means variant model and can be varied (0-9) or (A-Z).

Supplier	SAMSUNG	SAMSUNG	SAMSUNG
Model name	DW-BG970*	DW-BG770*	DW-BG570*
Rated Capacity (place setting)	14	14	13
Energy efficiency class	A+++	A++	A+
Eco label	No	No	No
Annual energy consumption, (AE C) (kWh/year)	236	256	276
Standard cycle energy consumption, (E t) (Kwh)	0.83	0.90	0.97
Power consumption off mode, P o (W)	0.45	0.45	0.45
Power consumption left-on mode, P I (W)	3	3	3
Annual water consumption (AW C), (L)	2800	2800	3360
Drying efficiency class	A	A	A
Standard programme	Eco	Eco	Eco
Programme time for the standard cycle	145	145	145
Duration of the left-on mode, (T I) (min)	10	10	10
Airborne acoustical noise emissions (dBA re 1pW)	40	43	45
Installation	Built-in	Yes	Yes
	Built-under	-	-
	Free standing	-	-

1) 'Standard programme' is the standard cleaning cycle to which the information in the label and the fiche relates, that this programme is suitable to clean normally soiled tableware, and that it is the most efficient programme in terms of combined energy and water consumption.

Programme chart

PROGRAMME CHART

Soil level	Intensive 70	Auto 40-65	Express 65	Eco 45	Quick 50	Delicate 40	Prewash
Amount of food remains	Heavy	Very light to Heavy	Normal	Normal	Light	Light	Very light
Program sequence	Prewash ▶ Mainwash ▶ 1st rinse ▶ 2nd rinse ▶ Hot rinse ▶ Dry ▶ End	Prewash ▶ Mainwash ▶ 1st rinse ▶ (2nd rinse) ▶ Hot rinse ▶ Dry ▶ End	Prewash ▶ Mainwash ▶ 1st rinse ▶ Hot rinse ▶ Dry ▶ End	Prewash ▶ Mainwash ▶ 1st rinse ▶ Hot rinse ▶ Dry ▶ End	Mainwash ▶ 1st rinse ▶ Hot rinse ▶ End	Prewash ▶ Mainwash ▶ 1st rinse ▶ Hot rinse ▶ Dry ▶ End	Cold rinse ▶ End
Washing time (Min)	148	90~148	87	145	34	83	17
Water consumption (L)	17	9.1~17	11.6	10 (DW-BG970, DW-BG770) 12 (DW-BG570)	10.5	10.1	3.7
Program Time (min)	148	90~150	87	160	34	83	17



The wash time may differ depending on the temperature of the supplied water.