

Appendix

Product data sheet

| | |
|--|----------------|
| SAMSUNG | SAMSUNG |
| Model identification | NV73J9770RS |
| Energy Efficiency Index per cavity (EEI cavity) | 81.4 |
| Energy Efficiency Class per cavity | A+ |
| Energy consumption required to heat a standardised load in a cavity of an electric heated oven during a cycle in conventional mode per cavity (electric final energy) (EC _{electric cavity}) | 0.95 kWh/cycle |
| Energy consumption required to heat a standardised load in a cavity of an electric heated oven during a cycle in fan-forced mode per cavity (electric final energy) (EC _{electric cavity}) | 0.70 kWh/cycle |
| Number of cavities | 1 |
| Heat source per cavity (electricity or gas) | electricity |
| Volume per cavity (V) | 73 l |
| Type of oven | Built-in |
| Mass of the appliance(M) | 45.9 kg |

Data determined according to standard EN 60350-1, EN 50564, Commission Regulations (EU) No 65/2014 and (EU) No 66/2014.

Energy saving tips

- During cooking, the oven door should remain closed except for turning food over. Do not open the door frequently during cooking to maintain the oven temperature and to save energy.
- Plan oven use to avoid turning the oven off between cooking one item and the next to save energy and reduce the time for re-heating the oven.
- If cooking time is more than 30 minutes, the oven may be switched off 5-10 minutes before the end of the cooking time to save energy. The residual heat will complete the cooking process.
- Wherever possible cook more than one item at a time.